

Treatex®

Wood Finishes from Professionals



WE KEEP IT SIMPLE



- On a base of natural sustainable raw materials such as linseed oil, sunflower oil, jojoba oil, beeswax, carnauba wax and candelilla wax.
- Contains no pollutants and very few solvents.
- Odourless.
- **Quick drying.**
- **2 coats in just 3 - 6 hours.**
- **No sanding between coats.**
- Very durable.
- Microporous or closed surface possible depending on application quantity.
- Complies with regulation DIN 68861-1B: resistance to substances such as wine, coffee, fizzy drinks, tea, beer etc.
- Complies with DIN EN 71-3: Safe for use on children's toys.
- Complies with DIN 53160: Sweat and saliva proof.
- Easy to clean with Treatex® Floor Care.
- Easy to maintain with Treatex® Wax Polish.
- Suitable for use on stairs, wood, cork, work tops and furniture.
- Recommendable for those with dust allergies; dirt and dust can be removed easily.
- Available in clear, satin, gloss or in a range of colours.
- Certified for commercial use: DIN-51131, EN-13893

Surface Treatment

Floor Preparation

- Sand the surface with 80-120 grit sandpaper.
- Remove all dust and dirt.
NB: Providing warmth and good ventilation will speed up the drying process, but coldness and humidity will slow down the process.
- Before applying Treatex® Hardwax Oil Traditional to the whole floor, please test on a small area first.
No sanding between coats.



Classic Treatment Method

- Stir the Hardwax Oil well before use. Apply thinly and evenly over the surface with a brush or Roller. The surface will dry in approx. 3 - 6 hours.
- Apply the second coat as above.
- Allow to dry overnight - the floor may then be used. The surface will reach maximum hardness after a further 24 hours.




Treatex® Hardwax Oil Gloss

Spruce



Mahogany



Oak Medium



Ebony



Oak Dark



Oak Light



Surface Treatment

Heavy-duty use in commercial settings

- Use a Treatex® Roller to apply Treatex® Hardwax Oil Traditional to the clean surface, allowing roughly 30g per m².
- Maintaining warmth and ventilation will enable the floor to dry within 4 - 8 hours.
- Apply with a roller a second coat of Treatex® Hardwax Oil, again allowing roughly 30g per m².
- Allow to dry thoroughly overnight - the floor may then be used. The surface will reach maximum hardness after a further 24 hours.



Coloured Products

- Floors should be sanded smooth finishing between 80 120 depending on type of machine used and all dust removed.

Stains:

- Treatex® Traditional Colours should be brushed on thinly and if necessary cloth off the excess. Finish with one or two coats of Treatex® Hardwax Oil Traditional Clear as required.
- We advise that when using colours, sufficient product is purchased to complete the project and when more than one tin is required it is advisable to mix them together before use. Stir thoroughly before use.

Treatex® Wax Primer

- 'used for first coat on oily timbers like Ippe, Teak, Jarrah Merbau etc'
- Remove loose dust and dirt with a broom or vacuum cleaner.
- Apply Treatex® Wax Primer thinly and evenly over the surface with a brush, roller or scraper.
- Allow to dry 3 hours - the floor may then be treated with Treatex® Hardwax Oil Traditional.



Cleaning, Maintenance and Repair

Care of your Treatex hard wax oil floor

- Keep the floor clean - the result of people walking on dirt and dust is no different to a high-powered sander at work! A good doormat will help. Use a soft Hoover or brush as and when required to keep your floor free from abrasive particles.
- When the floor gets dirty, wash using Treatex Floor Care - this contains vegetable oils and Carnauba wax. Other brands of cleaning products can contain detergents that might damage the surface - Treatex Floor Care is designed to help maintain the finish without turning the floor slippery. This product can be applied by mop or machine (using a white pad).
- For areas of high wear the floor can be renovated using Treatex Polish. This is a diluted version of the hard wax oil. Clean the floor thoroughly using Treatex Refreshment Cleaner and leave to dry. Once dry, apply the wax to a small area at a time, either by wiping on a thin coat using a lint free cloth - take care not to leave cloth marks, or by buffing using white pad under a slow machine again ensure the surface is buffed until no swirl marks are showing. Allow drying for two or three hours.

NB to protect your floor we would recommend all furniture be fitted with felt pads.

Repair

- Sand down damaged areas with 150 grit sandpaper following the grain of the wood.
- Then sand down with sandpaper of up to 280 grit.
- Continue by following the instructions given in the 'surface treatment' section.



Cleaning and Maintenance
Products

FAQ

What can I do if the surface becomes dull?

This dullness is often caused by using incorrect cleaning methods or materials. Use Treatex® Floor Care for day-to-day cleaning and maintenance. This will bring back the usual sheen to the surface.

What if the material does not dry within the specified time (8 hours)?

The most common reason for slow drying is over-application. If this is the case, the drying time is increased by up to a further 8 hours. Please ensure that adequate ventilation is provided.

What can I do if the floor doesn't seem to have enough "body"?

Since it is the material that gives the floor "body", it is likely that you have applied too little. Apply an additional thin coat of Treatex® Hardwax Oil Traditional.

Are there any advantages to applying larger quantities of the material?

The more you apply, the more hardwearing the surface becomes. However, applying larger quantities than recommended in the 'commercial use' section will have no added benefit and will not increase durability or "body". NB: applying larger quantities increases the drying time considerably.

What can be used to clean brushes or rollers?

Rollers and brushes can be cleaned with white spirit after using with Treatex Hardwax Oil.

Can I apply colours on top of the clear Hardwax Oil?

The stains or colours must be applied before the clear Hardwax oil. The pigments need to penetrate in to unfinished timber.

How can I avoid overlab marks?

The roller saturated with hardwax oil should be rolled out on an untreated area before crossing a treated area.

Treatex Ltd

Unit i, Oyo Business Unit
Howland Road
Thame
Oxfordshire
Ox9 3GQ

www.treatex.co.uk
info@treatex.co.uk

Treatex[®]

products in action



Treatex[®] Hardwax Oil
Traditional
Made in Germany